

INSTALLATION INSTRUCTIONS FOR PD2AP3C23

This process will outline how to install a Salco Products PD2AP3C23 Pressure Differential Aerator Pad.

1. Remove existing aerator pad.
2. Clean and inspect all gasket mating surfaces so they are free from debris.
3. Install the Salco PD2 pad. The side with the spherical buttons and the Salco logo should be facing the plate. The Salco logo should cover up the air inlet. **Some stretching may be required to line the holes in the pad with the holes in the plate.**
4. Install all nuts, bolts, and washers. The metal washers are required, however the rubber lined washers are not required. Torque to 40 – 50 ft-lbs. **Bolts should be tightened in a cross pattern.**