

INSTALLATION INSTRUCTIONS FOR PLASTIC RETROFIT COVER FOR THE 5015 BUTTERFLY GATE



Remove the aluminum cover and eyebolts from the gate.

Clean off any dirt or debris in the area that the plates are to be installed. The hinge plate will be placed at the lower center area of the picture.



Remove the two nuts that are on this side of the gate. If your gate has bolts instead of nuts surrounding the bottom center pan of the gate, the kit supplied also includes bolts to retrofit your gate. Please follow the instructions and replace the nuts with the bolts.



Position the hinge bracket over the studs. The hinge should fit easily over the studs.



Apply the lock washers and nuts. The nuts should tighten down firmly against the casting.



Install the latch by applying the bolt through the eyebolt and then through the gate eyebolt hole. Fasten the nut to the bolt and tighten, make sure that the eyebolt on the latch can swivel so you can latch the cover.



Now that the hardware is attached, it is time to adjust the hardware for a good fit up to the gate. First, tighten the hinge bolt so that it starts to draws the arm down. Apply the latch. If the latch is loose or tight then adjust the latch by turning. Adjust the cover until you get a good fit. When the latch cams over onto the cover, there should be a firm feel to the latch.



A conversion kit successfully applied to the gate.